

1. Find studs in the wall that you plan to mount to. Standard studs are 16" apart, so you will need one in between the two you mount into.
2. Hold the guitar holder on the wall with one of the mounting holes over the center of the stud. When it's where you want it, measure from the ceiling down to the hole and mark the wall in that spot.
3. With the guitar holder on a flat surface, put the 2" screws provided, into 1/4" into each mounting hole to get them started.
4. Place the guitar holder back on the wall and drill the screw through your mark, into the stud.
5. As you hold the other side up, measure down the same distance from the ceiling and/or put a level on the middle of the guitar holder to ensure that it is level.
6. When drilling both screws, make sure that you constantly feel tension as it drills into the wall. If it goes in too easy, you may have missed the stud.
7. Black Buttons: These are meant to be tight. If they don't press in by hand, simply get it started, cover button with a cloth, and lightly hit with a hammer or mallet.