

Luna LED Floor Lamp Assembly Instructions

1. Screw pole (B) into base (A) clockwise until tight. Then screw together poles (B), (C), (D) and (E) as in the diagram.
2. Screw the socket (F) onto pole (E) tightly. You may need to pull in any extra slack of the power cord from the base so the socket (F) can screw in tightly.
3. Screw the bulb (G) into the socket.
4. Screw the glass shade (H) onto the socket slowly until it is fastened, but not too tight. Due to the porousness of glass, if the globe is screwed on too tightly it may become difficult to remove when needed.

GENERAL PRODUCT INFORMATION:

THIS PRODUCT IS SUITABLE FOR DRY LOCATIONS ONLY.

IMPORTANT SAFETY INSTRUCTIONS:

AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK, THIS LAMP HAS A POLARIZED PLUG. THIS MEANS ONE PRONG IS LARGER THAN THE OTHER. THEREFORE, THE PLUG WILL ONLY FIT IN A POLARIZED OUTLET IN ONE WAY. IF THE PLUG DOES NOT FIT FULLY IN THE OUTLET, TAKE IT OUT AND TURN THE PLUG OVER TO INSERT THE PRONGS IN THE OPPOSITE WAY. IF IT STILL DOES NOT GO IN, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

Thank you for purchasing this Brightech product. We guarantee all of our products with a best-in-class warranty for any manufacturer defects. If you need assistance or are unsatisfied with your purchase. PLEASE REACH OUT TO US DIRECTLY.

at wecare@brightech.com or file a warranty claim at <https://brightech.com/pages/warranty-request>

