



Note:

1. The length of the wire mesh can be appropriately adjust according to the actual length, but the total length can not exceed 1020".
2. Set up the wire mesh on the frame and tie it well.
3. Always be careful of the sharp wire.
4. Put the PE top fabric on the wire mesh, tied it with the pole.
5. Do not forget the ground peg when complete the installation.