

2. Trimming the blind drop

- Hang the blind in the brackets and lock into place. Lower the blind until it reaches the required drop. Take note of how many slats will need to be removed to attain this drop. **Note:** the bottom slat will be replaced by the bottom bar.
- Relocate the cord stops from close to the top of the blind pull cord to near the bottom of the cords.
- Using a flat head screwdriver pop out the cap on the bottom rail, taking care not to damage the rail.
- Untie the knots underneath the bottom bar.
- Pull the cord from the bottom rail to remove it from the slats you wish to remove. Remove the number of slats required to achieve your drop, remembering the bottom slat will be replaced by the bottom bar.

Tip: Initially remove one slat **less** than you require as this allows for any half distances between window ledges and bottom bar (You can always re-adjust/re-trim later if required).
- Slide the bottom bar in between the last two string ledges (one string set above the bar and one below). Trim the side tapes **1cm** below the lower string ledge.
- Thread the cord through the centre of the string ledge and through the bottom bar. With the bottom bar resting on the lower ledge, check the blind is level, knot the cord and trim any excess.
- Raising the blind to a comfortable working height, lock in position. Carefully gather the excess tape below bottom rail and put it neatly into the cap hole, replace cap. **N.B.** Ensure that the bottom rail is tight to the above string ledge.
- Lower the blind. Relocate the cord stops and level off the pulleys by repositioning the knots and trim any excess cord.

