



Prestige

furnishings

1. **Measure** the length of one slat on the futon frame.
2. **Cut** the roll into strips according to the length of the slat. The roll is 25 ft (or 300 in) long enough to cover a queen-size frame.
3. **Peel** off the protective tape from the strips one-by-one, discard it.
4. **Adhere** the strips to the slats, you may do every other or every two slats depending on how many strips you have. You do not need to cover each slat, space them out to cover as much area as possible.
5. **Press** firmly. Allow at least one hour for the adhesive to dry before placing the mattress.