

## Installation Instructions



1. Determine the installation position of non marking nails.
2. Fix the non marking nail with a hammer.
3. Align the hook and hang the clock.
4. installation is complete.