

# ASSEMBLY INSTRUCTIONS

1. Carefully unpack and place all parts on a smooth surface and line them up as per the sketch
2. Fasten tube (B) onto the base (A), tube (C) onto tube (B), tube (D) onto tube (C), then fasten tube (E) onto tube (D), be careful not to twist power cord and tighten securely.
3. Place shade (G) into shade (F) onto the socket assembly, then tighten with the socket ring (H).
4. Please use on/off-40W bulb on the lamp (bulb not included).

## IMPORTANT SAFETY INSTRUCTIONS

This portable floor lamp have polarized plugs (one blade is wider than the other) as a feature to reduce the risk of electric shock. These plugs will fit in a polarized outlet only one way. If the plugs do not fit fully in the outlet, reverse the plug. If they still do not fit, contact a qualified delectrican. Never use with an extension cord unless plug can be fully insterted. Do not alter plugs.

