

## Quick Assemble Design

Save up to 30% of installation time



STEP 1

Insertion Slot



STEP 2

Insertion PC Panels



STEP 3

Locking  
(requires only half-turn)