

INSTALLATION GUIDELINES

The vanity base is already assembled. The handles need to be turned around and be careful to make sure to place screws into the screw hole in the handle. The vanity top needs to be secured to the vanity base using double-sided tape or silicone. The backsplash needs to be secured to the vanity top using silicone. Mirror is hung by inserting L screws into the wall and turned upward. The mirror brackets are hung on the L screws. If you have any questions you can contact us at our website.