









INSPIREDHOME®

Assembly Instructions

NO	PARTS LIST		QTY
①		Seat cushion 1350x560x200mm	1pc
②		Underframe 470x230x250mm	2pcs

NO	HARDWARE		QTY
A		Allen key M4x21x57mm	1pc
B		Bolt 1/4"x50mm	6pcs
C		Washer 1/4"x16x1.2mm	6pcs
D		Spring washer 1/4"x2mm	6pcs

STEP : 1

