

- Using the included screws, mount the brackets to the wall.
 - If you are mounting directly to a stud, you do not need to use the included drywall anchors.
 - If you are not mounting a stud, then drill a small hole into the drywall and gently hammer the anchor into it. Then screw the bracket into the anchor.
- Place the brackets attached to the mirror over the brackets that were screwed to the wall.