

## Correctly Measure Backrest/Armrest Cover Size

Don't



**Over the curve =  
Too long**

Inaccurate measurement

Right



**Lay flat. Measure  
seam-to-seam**

Straight line, edge to edge