Assembly instructions

Graphical					
Product Name	A: Allen Wrench	B: Screw Bolt	C: Screw Bolt	D: Screw Bolt	E: Adjustable foot mat
Specifications (quantity)	4# 1	M6∗30 8	M6∗30 4	M6∗50 4	2

Step 1: Insert the upper and lower parts of the leg frame into the gap, and install the backrest (be sure to pay attention to the curvature of the two legswhen assembling, and the two legs should face inward to match the gap).

Payspecial attention: do not lock any of the screws.





Step 2: Flip the seat board over and place it flat on a horizontal surface at aheight of about 70 cm. Invert the chair frame and attach it to the seat board.First, insert the connecting wood, then install the frame holes according tothe seat board holes.

Special note: Do not lock any of the screws.





Step 3: Adjust the balance of the chair, then lock all the bolts ofthe seat plate, and then lock the screws on the connecting wood and the backrest. If the assembled chair is uneven, you can adjust the balance by adjusting the feet.















① Allen Wrench

② Adjustable foot mat

③ Bolts for the connecting wood

④ Bolts for the backrest

⑤ Bolts for the seat board