

Assembly

1. Fix the Wheels (B) to the T shape up rights(A).
2. Joint two T shape uprights (A) with two Bar (C) at bottom by 8mm Bolts(G) using Wrench(F) fixed.
3. Using 8mm Bolts(G) Joint the Third Bar(C) with the uprights from the second holes.
4. Using 6mm Bolts(H) and the Handle Nuts(I) to fix the uprights. with 3 Basket holders (D) be sure the Basket holders in same direction.
5. Put the Wire basket(E) onto the Basket holder(D).
6. Change the Basket degree by pressing the clip button according to needs.

Parts List

A: T Shape Uprights	2 pcs	
B: Wheels	4 pcs	
C: Bar	3 pcs	
D: Basket Holder	3 pcs	
E: Basket	3 pcs	
F: Wrench	1 pc	
G: 8mm Bolt	6 pcs	
H: 6mm Bolt	6 pcs	
I: Handle Nuts	6 pcs	

Only For Assembly Not For Drawing

