







HARDWARE AT WF315178

Α		В	
	M8 x 40		M8
	Hex-head bolt (8pcs)		Flat washer (8pcs)
С	Tiex Tiesa ser (epee)	D	riat mainer (epee)
			_
	M8 x 30		M6 x 60
_	Hex-head bolt (16pcs)	_	Hex-head bolt (4pcs)
E	$(\!(eta)\!)$	F	
	ammanimum (L		
	M6 x 100		M6 x13mm
	Hex-head bolt (4pcs)		Hex-head bolt (4pcs)
G	_	Н	6
	MC v 42mama		
	M6 x 13mm Flat washer (8pcs)		L Bracket (4pcs)
	r lat washer (opcs)	J	L Blacket (4pcs)
		<u> </u>	
	Mini Fix Housing (4pcs)	_	Mini Fix Bolt (4pcs)
K	-{- }511111111111>	L	
	M3.5 x 16mm		M4 x 32mm
	Flat washer (40pcs)		Flat washer (40pcs)
М	A Smininin	N	
	M4 v 39mm		M6 v 30mm
	M4 x 38mm Flat washer (16pcs)		M6 x 30mm Wood Dowel (4pcs)
0	Tiat washer (Topes)	Р	Wood Bower (+pos)
	\mathcal{R}	-	
	D. II. (0)		M4
	Roller (8pcs)		Allen key (1pc)
Q			
	M5		
	Allen key (1pc)		
ASSEMBLY TOOLS REQUIRED (NOT INCLUDED)			

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

CAUTIONS:

- 1. Do not FULLY TIGHTEN the nut or nut bolt until all nut or bolt is ready assembled.
- 2. Do not OVER TIGHTEN the nut or bolt to avoid causing damages to the thread.
- 3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.













