

Hand Shower Holder



Easy installation



Install Ways:

1. Clean the smooth surface and dry it
2. Peel off the protective layer
3. Adhesive it on the surface then press firmly for 30 seconds
4. Waiting for 24 hours before hanging