

Assembly Instructions

PACKAGED

- | | |
|------------------------|-----------------------|
| (A) 1- Base Assembly | (F) 1- Upper Turning |
| (B) 4- Drip Tray | (G) 1- Lock Washers |
| (C) 1- Lower Turning | (H) 1- Flat Washers |
| (D) 1- Umbrella Holder | (I) 1- Machine Screws |
| (E) 4- Dowel Pins | (J) 4- Coat Hooks |
| | (K) 8- Wood Screws |

Read all instructions before starting assembly.

Step #1 Remove all the contents from the package checking that all of the components listed in "Packaged" are included. Prepare a flat, protected work surface where the product can be assembled.

Step #2 Place Lower Turning (C) upside down with Larger diameter facing up and install two Dowel Pin (E). Align Base Assembly (A) over protruding Dowel Pins (E) in Lower Turning (C) with counter bored holes facing you. Place one Lock Washer (G) with one Flat Washer (H) onto one Machine Screw (I) and drop into counter bored hole into matching threaded insert in Lower Turning. Loosely tighten.

Step #3 Place Assembly into upright position. Install two Dowel Pins (E) into two holes in Lower Turning. Align Umbrella Holder (D) with matching dowel holes into position and push into place.

Step #4 Align Upper Turning (F) with protruding hanger bolt over threaded insert plate in Lower Turning (C). Carefully rest into position and slowly turn to tighten. (Do not cross thread). Continue to turn until securely tightend*.

Step #5 Align one Coat Hook (J) over pilot holes in Upper Turning (F) and install two Wood Screws (K). Repeat with remaining hooks and securely tighten *all screws.

Step #6 Place drip tray (B) to each hole of Base Assembly (A).

(*)Caution:DO NOT OVERTIGHTEN

