

Easy To Install

1



Wipe Clean

2



Peel off Backing

3



Position & Align

4



Smooth out Edges