



1. On the wall that needs to be installed, determine the position and make drilling marks with a colored pen.



2. Drill holes at the marked positions.



3. Insert the plastic anchors into the drilled holes.



4. Put a washer on the screw..



5. Slide the stainless steel reinforcement angle brackets onto the screws..



6. Fix the rain shelter with screws and tighten them.



7. If multiple units are assembled, leave a 3-5 mm gap between each rain shelter, and then insert the connectors.



Metal Gasket



stainless steel angle bracket



Screw Glue



6\*50mm Screw



PVC Splicing Tape