

How to Install

1. Mark holes for mounting.
2. Punch holes with M8 drill (not included).
3. Insert expansion bolts into holes.
4. Tighten with screws.