

# JZSKAQ-000000 JZSKAQ-000200 JZSKAQ-000100 JZSKAQ-000300 Manual

## Installation Steps for Urine Partition:



1. The urinal partition with a size of 400 \* 900 should be installed at a suspended distance of 40CM from the ground and approximately 260CM from the urinal. Or it can be determined based on the distance between the urinals on site.

2. Installation steps,

A. First, use a pencil to locate the hole position of the angle code on the wall (you can place the board at the location you want to install, then place the angle code and make a hole mark on the wall with a pencil, or measure with a tape measure, paying attention to deducting the thickness of the board). Make the opening mark and drill the hole

B. After drilling the hole, put the rubber plug into the hole

C. Fix the angle code on the wall with screws (align the angle code hole with the rubber plug hole)

D. Install the board and fix the other side of the angle code on the board.

德:

## Installationsschritte für die Urinseparierung:

