

# **Installation Instructions for 36" Single Bathroom Vanity**

## **Note to Customer:**

This vanity is delivered fully assembled in two separate pieces: one base cabinet and one quartz top with an attached sink. Professional installation is required. Please follow the instructions below or provide them to your installer.

## **Installation Process**

### **Tools and Materials Required:**

- Level
- Tape measure
- Pencil or chalk
- Cleaning cloth
- Silicone adhesive (clear or white)

### **Step-by-Step Instructions**

#### **1. Preparation:**

- Clear the installation area and ensure the floor is level where the vanity will be placed.
- Confirm that the plumbing connections (water supply lines, drain) are properly positioned to fit through the pre-cut holes in the vanity.

#### **2. Position the Pieces:**

- Place the vanity base at the desired position.
- Use a level to make sure all sections are properly aligned.
- Mark the final position of the pieces on the floor with a pencil or chalk.

#### **5. Final Adjustments and Cleaning:**

- Verify that all the vanity base is level.
- Use a cleaning cloth to remove any debris or dust.
- The vanity base is now ready for the countertop installation or further use.

#### **6. Steps for Quartz top installation**

- **Dry Fit:** Place the quartz top to check alignment.
- **Apply Adhesive:** Remove the quartz, apply silicone around the top edge.
- **Position the Top:** Carefully place the quartz, press down gently.
- **Check Alignment:** Ensure the top is level.
- **Seal Edges:** Apply silicone if needed, then clean excess.

- **Let Set:** Allow adhesive to cure for 24 hours.

**Important Notes:**

- **Professional Installation Recommended:** For precision alignment and proper attachment, professional installation is strongly recommended to ensure a secure base.