



Wood Chair Assembly

- 1. Remove Bolts & Washers from underneath Bucket**
- 2. Install Bolts with Washers through the Swivel back into the Bucket**
- 3. Make sure the Knob Faces the Front of the Chair**