



Installation Steps

Step 1: Screw the 3 metal legs into the three-hole nuts.

Step 2: Fix the tripod, place the gasket, the glass top and another gasket on the nut in sequence.

Step 3: Screw the metal head into the nut.