



Universal Wood Shelf Bracket
Support d'Étagère Universel en Bois
Soporte Para Estante de Madera Universal

SATIN NICKEL • NICKEL SATINÉ • SATINADOS DE NÍQUEL

7

53810

13970

4

1397

Product of China
 Produit de la Chine
 Producto de China

© ClosetMaid Corporation 2016
 Ocala, FL 34471
 1-800-874-0008 (USA, Canada)
 www.closetmaid.com



WARNING

- Failure to obey installation instructions and warnings can result in injury or death.
- Use correct hardware for wall type. When using standards with hang track, standards must be secured to the wall. Do not overload.

FOR STUD INSTALLATION: Secure to the wall with #12 x 2 in. pan head screws directly into wood studs. (RECOMMENDED)

1. Find the studs where the brackets are to be mounted (distance between brackets cannot exceed 32 in.).
2. For 12 in. shelf installation, **12 IN. LABEL MUST BE FACING UP**. For 16 in. shelf installation, **16 IN. LABEL MUST BE FACING UP**.
3. Place bracket at desired height and mark where the top screw of the bracket will go with a pencil.
4. Drive a #12 x 2 in. screw into the wall at the marked location until the head is about 1/4 in. from the wall. Slide the bracket onto top screw.
5. Using a level, ensure bracket is straight and drive another #12 x 2 in. screw through the bottom hole of the bracket. Tighten the top screw.
6. Repeat steps 2 - 5 for additional brackets.

01-09842-12

16 IN.
40,64 CM