

ASSEMBLY INSTRUCTIONS


ASSEMBLY TIPS:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior to start of assembly.
- 3. Please follow attached instructions in the same sequence as numbered to assure fast & easy assembly.



WARNING!



















- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.



ASSEMBLY TIME

120 MINUTES

PARTS IDENTIFICATION

















A	LEFT SIDE PANEL		1 PC	J	DOOR		3 PCS
B	LEFT DIVIDER PANEL		1 PC	K	LEFT BACK PANEL		1 PC
C	RIGHT DIVIDER PANEL		1 PC	L	MIDDLE BACK PANEL		1 PC
D	RIGHT SIDE PANEL		1 PC	M	RIGHT BACK PANEL		1 PC
E	BOTTOM PANEL		1 PC	N	DRAWER FRONT PANEL		2 PCS
F	CROSS BRACE		1 PC	O	DRAWER BACK PANEL		2 PCS
G	CROSS PANEL		6 PCS	P	LEFT DRAWER SIDE PANEL		2 PCS
H	LEFT TOP PANEL		1 PC	Q	RIGHT DRAWER SIDE PANEL		2 PCS
I	RIGHT TOP PANEL		2 PCS	R	DRAWER BOTTOM PANEL		2 PCS

NOTE:

Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.

Z


HARDWARE IDENTIFICATION

NO	DESCRIPTION	FIGURE	Q'TY	NO	DESCRIPTION	FIGURE	Q'TY
1	GLUE 40g		1 PC	9	PLASTIC FEET Ø 15mm		6 PCS
2	WOODEN DOWEL Ø 8x30mm		56 PCS	10	HANDLE		5 PCS
3	CAM BOLT Ø 7x35.5mm		44 PCS	11	SHORT BOLT Ø 4x23mm		5 PCS
4	CAM LOCK Ø 15x12mm		44 PCS	12	HINGE		6 PCS
5	LONG BOLT Ø 9.5x55mm		4 PCS	13	SCREW Ø 4x15mm FOR HINGE		24 PCS
6	LONG SCREW Ø 4.3x35mm		8 PCS	14	DOOR CATCH		3 PCS
7	RAIL L = 350mm		2 SET	15	NAIL		64 PCS
8	SHORT SCREW Ø 3x10mm		24 PCS	16	STICKER Ø 20mm		8 PCS





Z7,Z10,Z12 not included in blister packaging.

NOTE:
Phillips head screw driver is required in the assembly process; however, manufacturer does not provide this item.



STEP 1





STEP 2




STEP 3




STEP 4




STEP 5




Apply glue on all wooden dowels to ensure integrity of the structure.



LEFT





Apply glue on all wooden dowels to ensure integrity of the structure.



RIGHT


STEP 6

Apply glue on all wooden dowels to ensure integrity of the structure.






LEFT

Apply glue on all wooden dowels to ensure integrity of the structure.




RIGHT

STEP 7




Apply glue on all wooden dowels to ensure integrity of the structure.

LEFT






Apply glue on all wooden dowels to ensure integrity of the structure.


RIGHT



STEP 8






LEFT





RIGHT

STEP 9





LEFT




RIGHT

STEP 10






LEFT





RIGHT

STEP 11




LEFT




RIGHT



STEP 12




STEP 13







STEP 14




LEFT




RIGHT



STEP 15




LEFT




RIGHT


STEP 16
COMPLETE





LEFT



RIGHT





Note : Dimension tolerance $\pm 5\%$

ANTI-TIPPING INSTALLMENT INSTRUCTIONS

FURNITURE TIPPING RESTRAINT

WARNING

Injury may result from tipping furniture.
This restraint may protect against tipping furniture.
Do not allow children to climb on furniture.
This restraint is not a substitute for proper adult supervision.
Failure to detach this restraint before moving the furniture
may result in injury and damage.

1. To attach the anti-tip strap, securely mount one end to the top of the case piece with the 5/8" screw.
2. Position the case piece against the wall in the desired location.
3. Pull the anti-tip strap taut and mark the position of where you will secure the other end on the wall.
4. Drill a 1-1/4" hole in the spot you marked.
5. Tap in plastic wall plug.
6. Fasten anti-tip strap with wall screw provided.

(Please install the anti-tipping kit in the middle of the case piece if only have one set of anti-tipping kit.)

