



Place the tabletop face down on a flat surface covered with a soft cloth.

Locate the pre-marked white semicircular alignment lines at both ends of the tabletop.

Position the two solid wood bases symmetrically on either side of the white lines, and secure each base to the tabletop with 6 self-tapping screws per leg.