



Required
Pozi 2 screwdriver

Step 1



This pack includes: 1 x roof frame, 1 x leftside, 1 x rightside, 1 x top support brace, 1 x back panel, 1 x canvas roof, 8 x 100mm screws, 12 x 50mm screws.

Step 2



Position the top brace on the leftside and fix using 2 x 50mm screws. Ensure taller leg is at the front and the bracket for the back panel is on the inside at the back.

Step 3



Position the rightside and attach the top brace using 2 x 50mm screws.

Step 4



Position the back panel on to the brackets on each of the sides, fix in place with 12 x 50mm screws places in the pre-drilled holes.

Step 5



Place the roof onto the frame , ensure the back of the roof is flush to the back legs.

Step 6



Raise the roof frame at the front until the top is level with the top of the front leg. Fix with 2 x 100mm screws. Repeat for the back of the roof.

Step 7



Repeat step 6 for the opposite side of roof.

Step 8



Pull the canvas roof over the roof frame.