

01 First place the four frames on the flat ground in order, the four corners of the metal sheets are snapped into the frame and close together



02 Fasten the four corners with hexagon screws



03 Insert the four fiberglass rods into the edge of the curtain in the order of length



04 Hook the spring into the frame slot pay attention to fix the four corners first, and tighten them symmetrically around



05 Put the support rod into the middle position of the card slot to make the frame stronger



06 Install four hanging pieces by parallel drilling, the upper and lower hanging pieces are symmetrical, and the assembly is completed after hanging the curtain

