

ASSEMBLY INSTRUCTIONS

BRL3366

1. Fasten tube(B) onto lamp base(A). Be careful not to twist power cord tighten securely.
2. Fasten tube(C) onto tube(B).
3. Fasten tube(D) onto tube(C).
4. Fasten tube(E) onto tube(D).
5. Fasten bulb(G, not included) onto socket .
6. Fasten shade(H) onto socket assembly(F)

IMPORTANT SAFETY INSTRUCTIONS

THIS PORTABLE LAMP HAS A POLARIZED PLUG

(ONE BLADE IS WIDER THAN THE OTHER) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK.

THIS PLUG WILL FIT IN A POLARIZED OUTLET

ONLY ONE WAY. IF THE PLUG DOES NOT FIT FULLY INTO THE OUTLET, REVERSE THE PLUG.

IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

