

1



2



3



- 1.) No tools are needed.
- 2.) Remove the existing front plate and endcaps.
- 3.) Snap on the endcaps to the panel and then drop the entire assembly down on to the existing back plate. The 3/4" lip on the back of the panel will slide down into the gap between the original metal back plate and the wall.

Baseboard
DUKOWSKI'S