

	<table border="0"> <tr> <td data-bbox="523 107 710 257"> </td> <td data-bbox="810 107 1024 257"> </td> <td data-bbox="1109 114 1295 264"> </td> </tr> <tr> <td data-bbox="518 280 710 309">COLD LED LIGHT BULB</td> <td data-bbox="798 280 1045 309">WARM HALOGEN LIGHT BULB</td> <td data-bbox="1125 280 1324 309">WARM LED LIGHT BULB</td> </tr> <tr> <td data-bbox="558 309 662 414" style="text-align: center;">X</td> <td data-bbox="790 336 1061 380" style="text-align: center;">Merchant recommendation</td> <td data-bbox="1165 309 1268 414" style="text-align: center;">X</td> </tr> <tr> <td data-bbox="518 414 710 448">NOT GOOD EFFECT</td> <td data-bbox="853 414 997 448">GOOD EFFECT</td> <td data-bbox="1125 414 1316 448">NOT GOOD EFFECT</td> </tr> </table>				COLD LED LIGHT BULB	WARM HALOGEN LIGHT BULB	WARM LED LIGHT BULB	X	Merchant recommendation	X	NOT GOOD EFFECT	GOOD EFFECT	NOT GOOD EFFECT
COLD LED LIGHT BULB	WARM HALOGEN LIGHT BULB	WARM LED LIGHT BULB											
X	Merchant recommendation	X											
NOT GOOD EFFECT	GOOD EFFECT	NOT GOOD EFFECT											
<p>1: Put Wire slightly from base to allow working space for assembly</p> <p>2: Carefully assemble the parts in order from ⑥→⑤→④→③ to the base E</p> <p>3: Take the ring ① from the socket ③ . (Important)</p> <p>4: Put the lampshade ② to the socket first, then assemble ring ① to the socket to fixed the lampshade in tight.</p> <p>5: Put the warm halogen bulb (MAX 100W) into socket, and test it whether it's working. If your bulb not working, first replace the bulb, and if it still doesn't work, please check whether the copper inside of the socket is pop-up.</p>													

	<table border="0"> <tr> <td data-bbox="523 1187 710 1337"> </td> <td data-bbox="810 1187 1024 1337"> </td> <td data-bbox="1109 1193 1295 1344"> </td> </tr> <tr> <td data-bbox="518 1359 710 1388">COLD LED LIGHT BULB</td> <td data-bbox="798 1359 1045 1388">WARM HALOGEN LIGHT BULB</td> <td data-bbox="1125 1359 1324 1388">WARM LED LIGHT BULB</td> </tr> <tr> <td data-bbox="558 1388 662 1494" style="text-align: center;">X</td> <td data-bbox="790 1415 1061 1460" style="text-align: center;">Merchant recommendation</td> <td data-bbox="1165 1388 1268 1494" style="text-align: center;">X</td> </tr> <tr> <td data-bbox="518 1494 710 1527">NOT GOOD EFFECT</td> <td data-bbox="853 1494 997 1527">GOOD EFFECT</td> <td data-bbox="1125 1494 1316 1527">NOT GOOD EFFECT</td> </tr> </table>				COLD LED LIGHT BULB	WARM HALOGEN LIGHT BULB	WARM LED LIGHT BULB	X	Merchant recommendation	X	NOT GOOD EFFECT	GOOD EFFECT	NOT GOOD EFFECT
COLD LED LIGHT BULB	WARM HALOGEN LIGHT BULB	WARM LED LIGHT BULB											
X	Merchant recommendation	X											
NOT GOOD EFFECT	GOOD EFFECT	NOT GOOD EFFECT											
<p>1: Put Wire slightly from base to allow working space for assembly</p> <p>2: Carefully assemble the parts in order from ⑥→⑤→④→③ to the base E</p> <p>3: Take the ring ① from the socket ③ . (Important)</p> <p>4: Put the lampshade ② to the socket first, then assemble ring ① to the socket to fixed the lampshade in tight.</p> <p>5: Put the warm halogen bulb (MAX 100W) into socket, and test it whether it's working. If your bulb not working, first replace the bulb, and if it still doesn't work, please check whether the copper inside of the socket is pop-up.</p>													