

Master Garden Products

TBS-30 Teak Stool Assembly Manual



Included Parts

- 1 × Round slatted seat top
- 1 × Square wooden frame
- 4 × Cylindrical legs
- 1 × Pre-assembled cross-brace
- 1 × Short cylindrical support bar
- 5 × 2" screws
- 15 × 1.5" screws

(screws are in a small cardboard package as shown, just above the legs in the photo Left)

Tools Needed

- Phillips screwdriver (manual or powered)

Step-by-Step Instructions

Step 1: Install Cross-Brace

- Take the pre-assembled X-shaped cross-brace.
- Position it between the legs, aligning each end with the lower pre-drilled holes on the legs.
- Secure each end with **1 × 1.5" screw** from the outside.
- *Use 4 screws total*

Step 2: Add Short Cylindrical Support

- Place the short cylindrical bar horizontally between two opposing legs, just above the cross-brace.
- Fasten each end with **1 × 1.5" screw** from the outside.
- *Use 2 screws total*

Step 3: Attach Legs to Square Frame

- Position the square frame upright.
- Align each leg vertically against the **center of each side** of the frame (not the corners).
- From the **outside of each leg**, drive **2 × 1.5" screws** through the leg into the square frame.
- *Use 8 screws total (2 per leg × 4 legs)*

Step 4: Attach Frame to Seat Top

- Flip the round seat upside down.
- Center the square frame beneath it, aligning with the 4 pre-drilled holes.
- Use **4 × 2" screws** to secure the frame to the seat top.
- *Use 4 screws total*

Final Inspection

- Confirm all screws are tight and flush.
- Ensure the stool sits level and stable.

