



by Stevens Industries, Inc.  
704 West Main St.  
Teutopolis, IL 62467  
P: 800.350.3270  
P: 217-857-7100  
F: 217-857-7101  
www.totmate.com

# TM2182

## Toddler Play Center



HARDWARE BAG# 0563-3313


### ATTENTION

Please unpack and assemble in an area away from children's activities. Remove all tools and excess materials from work area after assembly of unit is complete. Dispose of pallet and packaging materials in an environmentally friendly manner. If any parts are missing or damaged, please call Stevens for immediate parts replacement (1-800-350-3270). When ordering parts, give the Model Number and Color of the unit.

### PARTS for TM8362R

ITEM	QTY	DESCRIPTION
1	2	End U
2	2	Fixed Shelf
3	1	Top
4	2	Rail, Front-Back
5	18	Screw Conn HxDc Ni 7mmx 50mm

### HARDWARE / TOOLS INCLUDED



**Confirmat Bolt**  
(Screw Conn HxDc Ni 7mmx50mm)



**Hex Wrench**



### CAUTION – CHOKING HAZARD

Adult assembly required due to presence of small parts and sharp edges.

Illustrations and part numbers are for TM8362R. Basic assembly instructions are the same for models shown. 2-Person assembly recommended.

**NOTE:**  
Refer to exploded drawing for orientation of holes to parts.

### IMPORTANT!

Be sure to keep all parts supported during assembly to avoid damage. Do not over-tighten bolts or it will damage the pre-drilled holes. Snug fit is adequate.

**STEP 1:** Lay one **End (1)** on floor with the side having the most holes facing up.

**STEP 2:** Insert dowels on one **Fixed Shelf (2)** into holes on bottom of **End (1)**. Press firmly into place. Repeat with other **Fixed Shelf (2)** using next set of matching holes on **End (1)**.

**STEP 3:** Insert dowels on one **Top (3)** into remaining holes on **End (1)**. Press firmly into place.

**STEP 4:** Insert dowel on one **Rail (4)** into lower hole at top of **End (1)**. Make sure hole on long side of **Rail (4)** aligns with hole through **Top (3)**. Press firmly into place. Repeat for other **Rail (4)**.

**STEP 5:** Position other **End (1)** on top of assembly, so dowels on **Rails (4)**, **Top (3)** and **Fixed Shelves (2)** align with holes in End. Press firmly into place.

**STEP 6:** Secure **End (1)** from STEP 5 to **Rails (4)**, **Top (3)** and **Fixed Shelves (2)** with eight **Confirmat Bolts (5)** using **Hex Wrench**.

**STEP 7:** Carefully turn unit over, so other **End (1)** is facing up.

**STEP 8:** Repeat STEP 6 to secure other **End (1)** to **Rails (4)**, **Top (3)** and **Fixed Shelves (2)**.

**STEP 9:** Secure **Top (3)** to **Rails (4)** with two **Confirmat Bolts (5)**.

**STEP 10:** Carefully stand unit upright. Ensure all joints and bolts are tight. This completes the assembly.

