

A 1PC	B 1PC	C 2PCS	D 2PCS
E 4+1PCS	F 2PCS	G 8+2PCS	H 1PC

Dowel Block

① Pay attention to the direction of the feet, the side with 2 pre-drilled holes facing inward.

② Pay attention to the direction of the feet, the side with 2 pre-drilled holes facing inward.

Please tighten the screws to 70% first, and tighten all screws 100% after all parts are assembled.

③ Tap Dowel Block [D] gently with a rubber mallet to ensure it is secure.

④ Step 1: Attach Corner Brackets [F] to Panel Legs [C] with Screws [G] into pilot holes.
Step 2: Attach Corner Brackets [F] to Board [B] with Screws [G] by a self-tapping method. (No pilot holes)

⑤