

MX5003-C1WD
OPERATIONS MANUAL



4MODERN
HOME

- 1) Please turn off the power before installing the lamp (see fig A).
- 2) Remove the mounting bracket from the top box, then place the mounting bracket on the junction box. Then tighten with the junction box screw.
- 3) Connect the lamp power cord to the main power cord of the junction box (white to white, black to black)
- 4) Wrap the naked copper ground wire in the junction box around the green screw. Lock the green screw in the tooth hole. Connect the naked copper wire of the lamp and the naked copper wire of the junction box with the terminal.
- 5) Secure the canopy to the mounting plate using the mounting screws
- 6) Turn on the power in your circuit breaker (see fig B).