

INSTASET QUICK INSTALLATION GUIDE

TOOLS YOU'LL NEED:

- RAZER KNIFE
- GROUT FLOAT
- TAPE MEASURE
- PENCIL
- LEVEL
- PRY BAR
- TILE SPACERS (OPTIONAL)
- GROUT (OPTIONAL)

STEP 1 SURFACE PREPERATIONS:

- Wall/substrate must be free of any debris, dust, and/or loose paint.
- Wall must be leveled, non-porous, smooth, dry and flat.
- Wall/Substrate can be laid over an existing tile surface, as long as it meets the substrate requirements above.

STEP 2 MEASURE THE WALL

Using a tape measure, pencil, ruler and level (if needed), mark out the measurements of your space.

STEP 3 ADHERE ADHESIVE MEMBRANE TO WALL

- Roll out the adhesive onto the wall (inner side facing the wall). We recommend rolling the roll out in a vertical direction for a strong bonding (top to bottom).
- Follow any markings made previously to ensure a straight line. Repeat process with the entire wall.

STEP 4 OUTLETS/FAUCETS/SHOWER HEADS

- Using a razer knife, carefully cut through any openings and remove the excess adhesive.

STEP 5 FIRMLY PRESS DOWN

- Using a grout float, firmly press down the adhesive.

STEP 6 CLEAN THE TILE

- Using a clean rag, wipe down the back of the tile/mosaic. Make sure the backing of the tile/mosaic is dry and smooth.
- Tile should be as flat as possible.
- Must achieve >80% direct bonding to the adhesive.

STEP 7 PEEL

- Peel the top protective layer of the Instaset membrane to expose the front facing adhesive.

STEP 8 STICK

- Following the lines drawn previously, gently press the tile onto the adhesive. Use a pry bar for adjustments/repositioning when needed.
- Firmly press the tile into the wall to secure bonding.

STEP 9 GROUTING (OPTIONAL)

- Grouting may be optional depending on the usable and application. Check with the tile manufacturer's guideline for more details.



FIND MORE INSTASET RATED TILE PRODUCTS ON GBMGLASS.COM

**FOR MORE DETAILED
INSTALLATION TIPS, SEARCH
“INSTASET TILE ADHESIVE”
ON YOUTUBE.COM**

**HAVE QUESTIONS? CALL US
1 (888) 862-8397**