



# ASSEMBLY INSTRUCTION

DESCRIPTION : BEDSIDE

<b>HARDWARE</b>	<b>A</b>  WOOD DOWEL 8 X 25 1X10	<b>B</b>  CB SCREW M3.5X16MM 1X24	<b>C</b>  CB SCREW M4X38MM 1X16	<b>D</b>  CSK CAP M6X50MM 1X4	<b>E</b>  NAIL 5/8 1X25	<b>F</b>  L KEY 1X1	<b>G</b>  QUICKFIT CAP 1X8	<b>H</b>  MINIFIX 5654+5546 4 SETS	<b>I</b>  HANDLE AW 75-782A 160MM (METAL) 1X2	<b>I2</b>  HANDLE SCREW M4X35MM 1X4	<b>J</b>  PVC NAIL WITH PIN 5/8 1X4	<b>K</b>  DRAWER SLIDE 14" 2 SETS
-----------------	---	--	--	--	----------------------------------	---------------------------	----------------------------------	---	--	--	--	--

<b>PART LIST</b> 	<b>STEP 1</b> 	<b>STEP 2</b> 	<b>STEP 3</b> 	<b>STEP 4</b> 
----------------------	-------------------	-------------------	-------------------	-------------------

<b>STEP 5</b> 	<b>STEP 6</b> 	<b>STEP 7</b> 	<b>STEP 8</b> 	<b>STEP 9</b> 
-------------------	-------------------	-------------------	-------------------	-------------------

<b>STEP 10</b> 	<b>STEP 11</b> 	<b>STEP 12</b> 	<b>COMPLETED</b> 
--------------------	--------------------	--------------------	----------------------