

3/4" BAY WINDOW DRAPERY ROD INSTALLATION INSTRUCTIONS

Care Instructions: Clean with a soft cloth. Do not use abrasive cleaning agents, solvents or polishes.

SET INCLUDES:

(A) X10
(B) X10
(C) X5
(D) X2
(E) X2
(F) X1
 Extends 36-72"
(G) X2
 Extends 18-36"

YOU WILL NEED:

Pencil
 1/4" dia. drill bit
 Screwdriver

1

Extends 18-36"
 Extends 36-72"
 Extends 18-36"

Before installation, measure windows to determine appropriate drapery rod length.

2

Remove screw to separate the bracket (C). Beginning with the center window, measure approx. 6 inches from the wall corner and use L-bracket as a guide to mark location for mounting screws (A). Drill pilot holes into wall with 1/4" drill bit (not included).

3

Drywall
 (B)
 (A)
 (C)
 Adjustable

Insert wall anchors (B) and attach L-bracket using mounting screws (A). Wall anchors may not be necessary if drilling into studs. Reassemble the bracket (C), adjusting to desired depth. Tighten screw to secure.

4

6 inches

Repeat steps 2-3 for additional brackets. Use level if necessary. Note: Center bracket may not be needed for all applications.

5

CENTER ROD

Extend telescoping rod (F) slightly. Place drapery panels (not included) on the rod. Screw corner connectors (E) to each end of the rod.

6

CENTER ROD

Extend rod to desired length. Hang rod on brackets (C).