

Metal Frame TV Stand/Bookcase assembly

Instructions:

1. Take off the black screws from the big metal rectangles before starting the assembly
2. Screw the wood boards to the black frame with a drill, Make sure the side with more holes is facing down
3. Screw the layers with the black screws to the side metals to hold them together

