

MANUFACTURER MOLDING INSTALLATION GUIDELINES

Flush Stair Nose

- Remove molding from wrapper.
- Cut to required length as necessary with a power miter saw (for the cleanest cut). Be sure to wear a dust mask and appropriate eye protection when using a power miter saw.
- Apply a generous bead of construction adhesive along the clean stair.
- Touch the bottom of the molding to the stair riser and carefully roll the stair nose into place. Once the molding is in its final position, press down firmly with your hands over the length of the stair nose.
- Let adhesive cure according to directions. Finishing nails can be used for added security.

T-Molding / Reducer / End Cap

- Unwrap molding and ***set aside plastic trim track to recycle or discard.***
- Cut to required length as necessary with a miter box and saw.
- Allow 1/4" expansion gap on each side of the center mounting foot.
- Apply a scant bead of construction adhesive to the center mounting foot of the molding and gently press the molding into place.
- Let adhesive cure according to directions.

Quarter Round

- Remove quarter round from wrapper.
- Cut to required length as necessary with a miter box and saw.
- Cover expansion gap with quarter round and mechanically affix quarter round to wall or base board using an electric finishing nailer or brad nailer.

**Please note: per the manufacturer, plastic tracks are not recommended during molding installation due to potential thickness mis-match between the track and your flooring.*