

How to Install:

1. Clean the surface and dry it naturally.
2. Cut it to the desired length.
3. Tear off a section of 3M adhesive tape on both sides of the back, and fix one end.
4. Stick the wide side first, tear off the tape, and press it until the wide side is pasted to the floor.
5. Stick the narrow side the same way.
6. To paste the corner, you need to cut off the plane and wide side and retain the facade. After finishing, you need to cut off the excess part according to the actual condition.
7. After sticking, you can step on it, but it can't touch water within 10 hours.