



INSTALLATION INSTRUCTIONS

Rustic Slimline Console Table

1. Look for the pencil marks on the back of the slab outlining the mounting plate frame of the hairpin legs.
2. Attach the legs to the wood slab by placing each leg inside the pencil outline and insert the screws into the pre-drilled pilot holes.
3. Place the completed console against the wall where it will be secured to. Move the legs forward or backward until the surface of the wood is flat and the item is fully aligned with the wall.
4. Identify the center of the console wood top. (This is where the keyhole bracket is placed)
5. Make parallel marks on the wall in pencil indicating the top and bottom of the wood surface.
6. Remove the console.
7. With the marks acting as a guide, drill a hole in the center of the two parallel pencil lines.
8. Secure a flathead screw (not provided – based on your specific wall material) into the wall. Make sure the screw you choose fits into the large hole of the keyhole and is big enough to remain secure when slid into the smaller space of the keyhole.
9. Place the console table against the wall and move it slowly until the screw you inserted clicks into the large hole of the keyhole then slide the entire table very gently until the screw head secures into the smaller space of the keyhole bracket.
10. Test by gently tugging the console toward you. A secure connection has been made if the console does not pull away from the wall. Repeat step 9 until the console is fully secure.