



ASSEMBLY INSTRUCTION

DESCRIPTION : 3 DOOR SHOE CABINET

HARDWARE	A 16MM CB SCREW M3.5X16MM 1X26	B 38MM CB SCREW M4X38MM 1X6	C NAIL 5/8 1X23	D D1 D2 D3 3.5 KG MAGNET (1 HOLE) 3 SETS	E PVC SHELF SUPPORT 1X16	F DOOR SUPPORT SPRING 1X3	G G1 G2 MAS R4 1X1 MAS L4 1X2	H ROUND PLASTIC LEG (PVC) 1X5	I I1 I2 MINIFIX 5654+5546 6 SETS	J L-KEY 1X1	K QUICKFIT CAP 1X6

