Installation Instructions

1. Determine Mounting Location
Measure the window width and determine the desired curtain rod position.
Mark the bracket locations on both sides of the window.
Use a level to ensure the marks are aligned.
Recommended Placement:
Install the rod several inches above and outside the window frame to allow curtains to open and close freely.

---

2. Install Mounting Brackets
Position each bracket over the marked locations.
Mark screw hole locations.
Drill pilot holes if necessary.
Install wall anchors when mounting into drywall or other surfaces requiring additional support.
Secure brackets using the provided screws.
Confirm brackets are firmly attached before installing the rod.

---

3. Adjust Telescoping Rod Length
Extend or shorten the rod by sliding the telescoping sections.
Adjust the rod until the desired width is reached.
Maintain adequate overlap between sections for proper support.
Tighten or secure the telescoping sections according to the product design.

---

4. Attach Finials
Attach finials to both ends of the curtain rod.
Tighten by hand until secure.
Avoid excessive force to prevent damage to the finish.

---

5. Mount Curtain Rod
Place the assembled rod onto the installed brackets.
Ensure the rod is properly seated and supported.
Install curtains and adjust as needed.
