

# FARMHOUSE CHANDELIERS INSTALLATION INSTRUCTIONS

				
1. Unscrew the lamp arm nut and washer	2. Unscrew the upper lamp drum nut	3. Install the lamp arm on the upper drum base	4. Turn the lamp over	5. Unscrew the lower drum nut
				
6. install the lamp arm on the lower lamp drum base	7. Tighten the lamp arm nut and long Thread Pipe	8. Thread the black main wire through the long Thread Pipe	9. Thread the main wire through the gold open screw in the lamp drum	10. Twist all the black wires together with the black wire in the main line, and do the same with the white wires
				
11. Secure the long Thread Pipe to the opening screw	12. Adjust the distance between lamp arms	13. Install the upper lamp drum nut	14. Connect the other end of the chain to the chandelier, main wire runs through the chain	15. Remove the bracket from the ceiling plate
				
16. Connect the iron chain to the ceiling plate	17. Install the ground wire at the same time	18. And passing the main wire through the ceiling plate via the screwed tube	19. Install the lower lamp drum nut	20. Install the bracket on the ceiling
				
21. Disconnect the power and connect the wires	22. Fix the ceiling plate to the bracket with nuts	23. Remove the ring from the lamp holder	24. Install the glass lamp shade, screw on white ring to secure	25. Install the bulbs and tum on the power