



Installation steps:

1. Insert the lamp arm into the medieval
2. Tighten the lamp arm with the nut
3. Connect the same color lamp head wire with the same color lead wire
4. Put the lid on
5. Tighten the smooth nut
- 6-7. Connect the boom to the lamp body
8. Twist the canopy on the boom
9. Drill a suitable size hole in the ceiling, then insert the expansion rubber plug into the hole
10. Fasten the siding to the ceiling with screws
11. Connect the main line on the lamp body to the line reserved on the ceiling
12. Cover the lamp body on the hanging board
13. Tighten the trim nut
14. Install the light source (without bulb)

Attention:

1. Please cut off the power supply before installation to prevent electric shock
(installation by certified electrician is recommended)
2. Due to the different display, the actual color can be different from the image
3. Due to the manual measurement of lamp body size, there may be a deviation of 1 / 2 inch
4. If you have any questions or lost parts, please feel free to contact us and we will try our best to help you