



















# Assembly Instructions




**\*Don't fully tighten all the bolts till the very end!**

## PRE-ASSEMBLY PREPARATION:


- Please read through the instructions before beginning assembly.
- Clear out the space for assembly and lay out all of the parts based on the Parts List, extra room will allow you to easily determine if all the pieces are present.
- Keep small parts and pieces away from children until fully assembled.



Part no.	Part	QTY	Image	Part no.	Part	QTY	Image
A1	Right arm	1		G	Seat cushion	3	
B1	Middle back panel	1		H	Back cushion	3	
B2	Right back panel	1		I	Back cushion	1	
B3	Left back panel	1		J	Bolt (M6*45mm)	16	
C1	Left front panel	1		K	Bolt (M6*35mm)	8	
C2	Right front panel	1		L	Bolt (M6*15mm)	4	
D	Seat panel	3		M	Washer M6	28	
E	Foot	2		N	Allen wrench	1	
F	Foot	2					

**Step 1:** Attach left back panel B3 to feet F, using Allen wrench N. Note: Don't fully tighten the bolts.






**Step 2:** Attach right back panel B2 and middle panel B1 with 2pcs bolts K and 2pcs washers M, attach front panels C1&C2 with 2pcs bolts K and 2pcs washers M, using Allen wrench N. Don't fully tighten the bolts.




K		M6*35	4
M		Ø16*Ø6.5*1	4



**Step 3:** Attach right arm A1 to back panels B1&B2 with 2pcs J and 2pcs washers M ,using Allen wrench N.Note: Don't fully tighten the bolts.




J		M6*45	2
M		Ø16*Ø6.5*1	2



**Step 4:** Attach left back panel B3 and foot F to back panels B1&B2 with 2pcs bolts J and 2pcs washers M,using Allen wrench N.Note:Don't fully tighten the bolts.




J		M6*45	2
M		Ø16*Ø6.5*1	2



**Step 5:** Attach front panel C1&C2 to right arm A1 and left back panel B3 with 4pcs K and 4pcs washers M, using Allen wrench N, Note: Don't fully tighten the bolts.




K		M6*35	4
M		Ø16*Ø6.5*1	4



**Step 6:** Attach seat panels D to front panels C1&C2 and back panels B1&B2 with 12pcs bolts J and 12pcs washers M, using Allen wrench N. Note: Don't fully tighten the bolts.



J		M6*45	12
M		Ø16*Ø6.5*1	12

**Step 7:** Attach feet E to seat panels D with 4pcs bolts L and 4pcs washers M, using Allen wrench N. Note: Please fully tighten the bolts.



L		M6*15	4
M		Ø16*Ø6.5*1	4

**Step 8:** Put seat cushions G and back cushion H&I onto the seat. Assembly is now complete and the product is ready for use.

