
# Hall Tree

**Assembly Instructions - Please keep for future reference**



## Dimensions

Width- 59.05inch

Depth- 15.75inch

Height- 78.74inch

**WARNING**




This product is NOT a Clothing Storage Unit (CSU).
DO NOT use it for clothing storage.
Improper use may cause furniture tipover.

**Important – Please read these instructions fully before starting assembly**

# Safety and Care Advice

## Important – Please read these instructions fully before starting assembly

• Check you have all the components and tools listed on the following pages.

• Remove all fittings from the plastic bags and separate them into their groups.

• Keep children and animals away from the work area, small parts could choke if swallowed.

• Make sure you have enough space to layout the parts before starting.

• During assembly do not stand or put weight on the product, this could cause damage.

• Assemble the item as close to its final position (in the same room) as possible.

• Assemble on a soft level surface to avoid damaging the unit or your floor.

• Parts of the assembly will be easier with 2 people.



• To reduce the likelihood of damaging your product please ensure that your power drill is set on a low torque setting.

## Care and maintenance

• Only clean using a damp cloth and mild detergent, do no use bleach or abrasive cleaners.

• From time to time check that there are no loose screws on this unit.

• This product should not be discarded with household waste. Take to your local authority waste disposal centre.

## Handy Hints

• Assemble all parts and bolts loosely during assembly, only once the product is complete should you fully tighten the bolts

• Regularly check and ensure That all bolts and fittings are tightened properly.

## WARNING
**In order to help prevent overturning – please follow these instructions**











To help prevent product toppling over please follow the below steps:-

Use the anti tip stap or wall fixing method provided (if applicable)
Do not allow children to climb or hang on the furniture
Do not open more than one drawer at a time
Do not place heavy items in the top drawers
Do not place heavy items on top of the furniture, unless the furniture has been designed for this purpose


# Components - Fittings

## Please check you have all the panels listed below


Note:The quantitie below are the correcet amount to complete the assembly. In some cases more fittings may be supplied than are required.

| | | | |
|---|---|---|---|
| A  Cam Bolt ×87+2 | B  Cam Bolt ×87+2 | C  6*30mm Dowel ×71+2 | D  4*40mm Screw ×24+1 |
| E  Coat Hook ×6 | F  3.5*14mm Screw ×40+2 | G  Back Panel Clip ×28+1 | H  Shelf Bracket ×8 |
| I  Hole Cover ×34+2 | J  Felt Pad ×8 | K  Anti-tip Device ×2set | L  Allen key ×1 |

## Tools required Not Included




Phillips screwdriver
(medium & large)



# Using Camlocks


## Step 1

Connect the male camlock as diected in the assembly instructions using a scewdriver.




## Step 2


Push the male camlock into the entry hole.




## Step 3

Insert the female camlock as shown in the instruction.

Note：ensure that the arrow on the top of the camlock points towards the entry hole for the male camlock.





## Step 4


Turn the female camlock clockwise with a screwdriver.

You should feel a click when the camlock is locked in place.

The joint is now secure.




# Assembly Instructions




# PART LIST


This product comes in 2 box.




⑧
×1
1500×400×15




⑨
×2
1498×60×15



⑪
×1
1395×40×15



⑬
×1
1500×400×15




⑮
×1
1507×267×15




⑯
×1
1507×267×15




⑰
×2
1507×40×15




⑱
×1
1436×61×15




⑲
×1
1436×100×15




⑳
×1
1436×61×15




㉑
×2
1444×383×3




㉒
×1
1444×297×3




㉓
×1
1436×266×12



㉔
×1
1387×40×15




㉘
×1
1500×300×15




㉙
×2
312×40×15

# PART LIST


This product comes in 2 box.




① ×1
373×373×15




② ×1
373×373×15



③ ×1
373×373×12



④ ×1
373×373×12




⑤ ×1
373×373×12




⑥ ×2
373×40×15




⑦ ×3
333×40×15




⑩ ×2
368×60×15



⑫ ×4
381×358×3




⑭ ×1
350×350×12




㉕ ×3
233×266×12




㉖ ×3
233×40×15



㉗ ×4
240×356×3




㉚ ×1
350×350×12




Hardware kit ×1


# Assembly Instructions


## Step 1




## Step 2





×2

# Assembly Instructions

## Step 3




C




6*30mm Dowel ×4

B




Cam Bolt ×5

## Step 4





A




Cam Bolt ×4

# Assembly Instructions


**Step 5**





| | |
|---|---|
| C  6*30mm Dowel ×4 | |
| B  Cam Bolt ×4 | |

# Assembly Instructions


**Step 6**




| | |
|---|---|
| C  | 6*30mm Dowel ×4 |
| B  | Cam Bolt ×6 |


# Assembly Instructions


**Step 7**




# Assembly Instructions

## Step 8










## Step 9



# Assembly Instructions


**Step 1 0**





| | |
|---|---|
| C  | 6*30mm Dowel ×4 |
| B  | Cam Bolt ×6 |

# Assembly Instructions


**Step 1 1**




# Assembly Instructions


**Step 1 2**





| | |
|---|---|
| C  | 6*30mm Dowel ×4 |
| D  | 4*40mm Screw ×4 |

# Assembly Instructions


**Step 1 3**





| | |
|---|---|
| B  Cam Bolt ×5 | |
| A  Cam Bolt ×10 | |

# Assembly Instructions


**Step 1 4**





| | |
|---|---|
| C  6*30mm Dowel ×3 | |
| D  4*40mm Screw ×4 | |

# Assembly Instructions


**Step 1 5**





×2





**Step 1 6**







# Assembly Instructions

## Step 1 7




C




6*30mm Dowel ×2

B




Cam Bolt ×2

## Step 1 8




C



6*30mm Dowel ×4


D




4*40mm Screw ×4

# Assembly Instructions


**Step 1 9**





×3





**Step 2 0**





# Assembly Instructions


**Step 2 1**





**Step 2 2**




# Assembly Instructions


**Step 2 3**





| | |
|---|---|
| C  6*30mm Dowel ×6 | |
| D  4*40mm Screw ×6 | |

# Assembly Instructions


## Step 2 4





×2





## Step 2 5





# Assembly Instructions


## Step 2 6





## Step 2 7





# Assembly Instructions


## Step 2 8





## Step 2 9




# Assembly Instructions


**Step 3 0**





| | |
|---|---|
| C  6*30mm Dowel ×10 | |
| B  Cam Bolt ×10 | |

# Assembly Instructions


**Step 3 1**






×2


**Step 3 2**





**Step 3 3**




# Assembly Instructions

**Step 3 4**




# Assembly Instructions


**Step 3 5**





×3




**Step 3 6**






×3



# Assembly Instructions


**Step 3 7**




| | |
|---|---|
| C  6*30mm Dowel ×6 | |
| D  4*40mm Screw ×6 | |


# Assembly Instructions


**Step 3 8**



# Assembly Instructions


**Step 3 9**



# Assembly Instructions


**Step 4 0**





| | |
|---|---|
| C | 6*30mm Dowel ×10 |
| B | Cam Bolt ×10 |

# Assembly Instructions

**Step 4 1**




F




3.5*14mm Screw ×28


G



Back Panel Clip ×28





1





2



# Assembly Instructions

**Step 4 2**




| | |
|---|---|
| I  | Hole Cover ×34 |
| F  | 3.5*14mm Screw ×12 |
| E  | Coat Hook ×6 |

# Assembly Instructions

**Finish**

