

Instruction



1.用短螺丝固定扶手上
FIX THE HANDRAIL WITH SHORT SCREWS



2.在墙上做记号
MARK ON THE WALL



3.将短螺丝从扶手上卸掉
REMOVE THE SHORT SCREW FROM THE HANDRAIL



4.冲击钻打孔
PERCUSSION DRILLING



5.将涨塞打入墙体
DRIVE THE EXPANSION PLUG INTO THE WALL



6.用长螺丝将墙托固定在墙上
FIX THE WALL BRACKET ON THE WALL WITH LONG SCREWS



7.用短螺丝固定扶手上
FIX THE HANDRAIL WITH SHORT SCREWS